

Always make sure your firearm is unloaded prior to cleaning.

1. Use Bore-Max™ Speed Brush™ to vigorously scrub the inside of the bore, breach to muzzle, to agitate the fouling.
2. Add Bore-Max Foaming Bore Cleaner to your bore at the breach. Point muzzle slightly downward (let it work for 10 – 15 minutes).
3. Center-spike Speed Jag Patch™ over Speed Jag™ evenly, ensuring it covers the jag on both sides.
4. Run Speed Jag and Patch through the bore (breach to muzzle). Continue repeating this step with a fresh patch until the patch is clear of fouling residue.
5. Fouling is removed in layers, so repeat steps 1 through 4 until all fouling is clear (indicated by a clear patch on the first pass in step 4).

DO NOT USE EXCESSIVE FORCE

